



### Why Choose Remote Surface Mounted Controller 10 Amp FC-ITR-10D

RSMC2 - a 10 Amp Triac which allows remote control of up to 6 MAC10 Fan Filter Units

Allows complete control of airflow of up to 6 Mac 10 fan filter units

IP54 rated for demanding cleanroom environments

Ideal for soft and hard wall cleanrooms

### Lead time (if out of stock)

10-14 days

### More Info

RSMC2 - a 10 Amp Triac which allows remote control of up to 6 MAC10 Fan Filter Units

Allows complete control of airflow of up to 6 Mac 10 fan filter units

IP54 rated for demanding cleanroom environments

Ideal for soft and hard wall cleanrooms

### Applications

Designed with Cleanroom Applications in mind An electronic speed controller which controls the speed of single phase voltage motors. The motor starts according to the position of the potentiometer and the minimum speed setting can be adjusted internally with a trimmer. IP54 rated casing for demanding clean room environments. Ideal for soft-wall and hard-wall clean rooms.

## Country of origin

Belgium

## Technical data

Choice of 2 controllers: 3 Amp – allows remote control of a single MAC10 Fan Filter Unit – our code RSMC1. 10 Amp - allows remote control of up to 6 MAC10 Fan Filter Units – our code RSMC2 RSMC1: Current rating: 0.3-3A, Fuse rating 5A. IP54 rated case. Illuminated on / off switch. Min speed is pre-set at 100V. Product weight 0.35kg RSMC2: Current rating: 1-10A, Fuse rating 16A. IP54 rated case. Illuminated on/off switch. Min speed is pre-set at 100V. Product weight 0.71kg

## Sterility

Non-Sterile



[www.cleanroomshop.com](http://www.cleanroomshop.com)  
Tel: + 44 (0) 1524 813022

[info@cleanroomshop.com](mailto:info@cleanroomshop.com)  
Fax: + 44 (0) 1524 811589